

GUIDE: REPLACING A SCREEN

For step-by-step video tutorials, please visit the Champion Windows & Home Exteriors YouTube channel.

REMOVING STANDARD SCREENS FROM A WINDOW

Note: Do not lean against screens, they do not act as safety barriers.



Step 1

Open the window so you can reach the screen. On double-hung windows, you can use the tilt-in feature of the sash. Raise the screen a few inches so you can grasp the top and bottom.



Step 2

Push the screen to the side containing the screen spring, compressing the spring and allowing the screen to be removed from the track. Pull the damaged screen out through the window opening.





Step 3

To re-install the screen, reinsert the spring side of the screen into the side track and compress to insert into the opposite side track. You can now lower the screen into the bottom track and close your window.